

High Performance in Compact Design

The perfect wheel balancer for shops desiring to expand into wheel service and looking for value without compromising balancing features.

“RPI” Real Plane Imaging Technology

- Simply start measuring run by closing of wheel guard or pressing START key
- Optimisation, spoke mode with hidden weight function and EASYALU mode
- 19” color monitor
- 10 weight compartments with ample space in weight storage and within easy reach of the operator
- User-friendly graphical interface
- Motor drive with V-belt for constant rotational speed during measuring run
- Perfect solution to optimise the working space
- 2D Semi Automatic Parameter Entry (SAPE)
- Optional accessory: motorcycle adaptor (EAK0221J86A)



b9600
Wheel Balancer

JohnBean™


Standard Accessories



19" monitor with graphical interface



Membrane touch key



Split weight mode, adhesive weights can be hidden behind adjacent spokes of alloy rim



Gauge arm equipped with weight clamp retains the wheel weight in the correct position for weight placement.

Technical Data

Model	b9600
Resolution	1g
Measuring Speed	200 rpm
Measuring Time	6 - 10 s
Rim Width (Dynamic)	1" - 16" (3" - 16")
Maximum Wheel Width	500 mm (400 mm with wheel guard)
Rim Diameter	12" - 22"
Maximum Wheel Diameter	1,016 mm (880 mm with wheel guard)
Data Entry	2D SAPE
Maximum Wheel Weight	65 kg
Power Supply	220 - 240V, 1Ph, 50/60 Hz

SINGAPORE

Snap-on Tools Singapore Pte Ltd
25 Tagore Lane, #01-02,
Singapore 787602
Tel: (65) 6451-5570 • Fax: (65) 6451-5574

INDONESIA

Snap-on Tools Singapore Pte Ltd - Indonesia Rep. Office
Graha Pratama Building, 20th Floor
Jl. M.T. Haryono Kav 15, Jakarta 12810, Indonesia
Tel: (62-21) 8370-9611 • Fax: (62-21) 8370-9612

MALAYSIA

Snap-on Tools Singapore Pte Ltd - Malaysia Branch
Unit A-2-3, Block A, 3-2, Jaya One
No. 72A, Jalan Universiti
46200 P.J., Selangor, Malaysia
Tel: (603) 7957-3088 • Fax: (603) 7958-2088

PHILIPPINES

Snap-on Tools Singapore Pte Ltd - Philippines Branch
4/F, 2053 Building, Edison Street, San Isidro
Makati City, 1234 Philippines
Tel: (63-2) 843-7935 • Fax: (63-2) 843-7730

TAIWAN

Snap-on Tools Singapore Pte Ltd - Taiwan Branch
3F-4, #9 Wuquan 1st Road, New Taipei Industrial Park
Xinzhuang District 24892, New Taipei City, Taiwan ROC
Tel: (886-2) 2298-9789 • Fax: (886-2) 2298-2288

HONG KONG

Snap-on Tools Hong Kong Limited
Unit 2010, 20/F, Laford Centre, 838 Lai Chi Kok Road
Cheung Sha Wan, Kowloon, Hong Kong
Tel: (852) 2370-3700 • Fax: (852) 2370-3400

KOREA

Snap-on Tools Korea
#505 & 506, BuCheon Techno Park Block 3,
Building 301, 365 SamJung-Dong, OhJung-Gu
Bucheon City, GyeongGi-do, Korea 421-809
Tel: (82-32) 326-7310 • Fax: (82-32) 326-7312

THAILAND

Snap-on Tools (Thailand) Co. Ltd.
5th Floor, Talomsim Building, 924 Rama 3 Road
Bangpongpang Yannawa, Bangkok 10120, Thailand
Tel: (66) 2294-9660 • Fax: (66) 2294-9665